

COVSEAT4

Instructions

TOOLS REQUIRED FOR ASSEMBLY

Adjustable Wrench, or 14 mm (0.55 in.) open end or socket.
(not included)

ASSEMBLY INSTRUCTIONS

- 1- Unpack all parts before discarding / recycling the packaging material.
- 2 -Assemble the casters (11) to the tray (9), sub-frame (10), and tray divider (7) as shown, and tighten.
- 3 - Place the pneumatic cylinder (6) into the base as shown.
- 4 - Place the seat top (1) onto the pneumatic cylinder ram as shown.

NOTE: The pneumatic cylinder is taper fit to the base and seat top and requires no hardware. Please check that the connecting surfaces are clean and dry before assembly. Firmly press down on seat. Lift the seat by the top cushion to ensure positive connection.

USAGE

RAISING THE SEAT: Once the seat top is securely attached to the pneumatic ram, lift the height adjustment lever (2) without putting any weight on the seat. This will raise the seat to its maximum height.

LOWERING THE SEAT: Pull up on the adjustment lever while sitting on the seat to lower it to its lowest height. The seat can be adjusted to any height by releasing the adjustment lever at the desired height.

CAUTION

⚠ This seat may tip over if any caster wheel(s) are caught in a crack, seam, on a rock, pebble or other obstacle, or when used on soft carpeted floors.
Use caution when moving the seat while seated on it.



COVSEAT4

Instruction

ASSEMBLY DIAGRAM & PARTS LIST

Pt.	Description	Qty
1	SEAT	1
2	HEIGHT ADJ. LEVER	1
3	14 mm (0.55 in.) NUT	5
4	SPRING WASHER	5
5	WASHER	5
6	CYLINDER	1
7	TRAY DIVIDER	1
8	MAGNETIC PAD	1
9	TRAY	1
10	SUB-FRAME	1
11	CASTER	5

